


Verizon Mobile Hotspot Connection Instructions

Please unbox and power on the Hotspot by pressing the power button on the top side of the unit above the display screen. (Unit is battery powered, if your provided unit does not power on, please use the included wall adapter to charge.)


On the touchscreen, push “Menu”




On the next Menu Screen push: “Wi-Fi”



On the next Menu Screen push: “Wi-Fi Name/Password”




Please note the Primary Network Name and Password:




Log in on your Chromebook device

Please navigate to your WiFi Connection Icon on your device (district Chromebook pictured below)



Then select your Hotspot by name from the drop down menu.



Once the Hotspot is selected, you will be prompted for a password; enter the password you noted previously. After the password is entered, hit the connect button.

